


SGS Prime COGO

Feature Comparison

COGO Menu




Point Traverse 2D	Lt	Std	Pro
Basic - Calculate points by direction, distance and offset.	✓	✓	✓
Basic with Backsight - Calculate points by turned angle from backsight, distance and offset.	✓	✓	✓
Standard - The default version, a complete COGO solution with Inverse and Intersection calculation capabilities.	✓	✓	✓
Inverse Calculations	Lt	Std	Pro
Inverse Points - Find the direction, horizontal and slope distances, slope and coordinate differences between two points. Calculation methods include Point to Point , Radial Ties (to calculate inverses to multiple points from a base point), and Point Chain (to calculate inverses of sequential courses). The Point to Point option allows the user to calculate coordinates of any station and offset between the two points, calculate multiple points by distance interval and offset, or by equal partition and offset.	✓	✓	✓
Inverse Curve (Radial Point) - Find all the curve elements by entering points at the beginning and end of the curve, the radius point and the direction of the curve. Calculate coordinates of any station and offset along the curve, calculate multiple points by distance interval and offset, or by equal partition and offset.	✓	✓	✓
Inverse Curve (Three Point) - Find all the curve elements by entering points at the beginning and end of the curve, and a third point on the curve. Calculate coordinates of any station and offset along the curve, calculate multiple points by distance interval and offset, or by equal partition and offset.	✓	✓	✓

Inverse Calculations	Lt	Std	Pro
Inverse Angle - Calculate the turned angle at a station by entering the station, backsight and foresight points. Distances to both backsight and foresight are also calculated.	✓	✓	✓
Inverse Point to Line - Enter 2 points along a baseline and a offset point to calculate the offset distance perpendicular to the line, the distances along the baseline that the offset point is perpendicular.	✓	✓	✓
Inverse Point to Curve - Enter beginning of curve and end of curve points, a radius point and a offset point to calculate the offset distance perpendicular to the curve, the distances along the curve that the offset point is perpendicular.	✓	✓	✓
Intersections	Lt	Std	Pro
Bearing-Bearing - Intersect directions from two known points. Perpendicular offsets can be entered for both directions.	✓	✓	✓
Distance-Distance - Intersect distances from two known points.	✓	✓	✓
Bearing-Distance - Intersect a direction from a known point, with a distance to another known point. A perpendicular offset can be entered for the direction.	✓	✓	✓
Distance-Interior Angle - Intersect a distance from a known point with an angle to another known point.	✓	✓	✓
Areas / Closures	Lt	Std	Pro
Area by Points - Calculate the area of a polygon by entering the points along the perimeter. Curved and straight segments can be entered. The polygon is drawn on the screen, and can be exported as a DXF file.	✓	✓	✓
Subdivide by Sliding Bearing - Subdivide a specified area by sliding a line of fixed bearing. Solution points can be stored, and the calculated polygon can be exported as a DXF file.	—	✓	✓
Subdivide by Hinge Point - Subdivide a specified area by swinging a line from a hinge point into another line of fixed bearing. Solution points can be stored, and the calculated polygon can be exported as a DXF file.	—	✓	✓
Closures - Calculate closures by entering dimensions of straight and curved segments. The report includes the precision, length, area and misclose information. Results can be exported to a text file, a HTML report, a DXF file, or points stored in the project database.	—	✓	✓

Fit Points	Lt	Std	Pro
<p>Fit to Straight Line - Calculate the least squares line that best fits a series of points (linear regression). The direction (azimuth/bearing) of the line and its standard deviation, the Y-Intercept and its standard deviation, and correlation are calculated. Perpendicular offsets can be viewed for each point and the points can be shifted to fall on the line.</p>	-	✓	✓
<p>Fit to Circular Curve - Calculate the radius and the coordinates of the radius point of the least squares circle that best fits a series of points. When providing points along one or both tangents, the program will also solve the BC and/or EC point coordinates. It is possible to enter a radius for the curve that differs from the best-fit radius and recalculate a new least squares circle with the fixed parameter. Radial offsets can be viewed for each point, and the points can be shifted to fall on the curve.</p>	-	✓	✓
<p>Double Proportion - Enter the 4 points for the North, East, South and West section corners and the record measurements to the lost section corner to calculate the coordinates as per the Double Proportionate Measurement method (BLM).</p>	-	✓	✓
<p>Irregular Boundary - A combination of single proportion and compass rule is used to re-establish a lost corner as per the Irregular Boundary Adjustment method (BLM).</p>	-	✓	✓
<p>Grant Boundary - Calculate the positions of lost angle points as per the Grant Boundary Adjustment method (BLM).</p>	-	✓	✓

Adjust Menu



Compass Rule	Lt	Std	Pro
<p>Closed Figure - Perform a compass rule adjustment on a series of points in a closed loop. The precision, perimeter and misclose</p>	✓	✓	✓


Compass Rule	Lt	Std	Pro
information is calculated. Review pre- and post-adjustment course dimensions and optionally adjust the point coordinates.			
Close to Fixed point - Perform a compass rule adjustment on a series of points closing on a fixed point. The precision, length and misclose information is calculated. Review pre- and post-adjustment course dimensions and optionally adjust the point coordinates.	✓	✓	✓
Rotate / Mirror	Lt	Std	Pro
Rotate around Base Point - Rotate a series of points around a specified base point by a entered or calculated angle.	✓	✓	✓
Rotate around Origin (0,0) - Rotate a series of points around a 0,0 by a entered or calculated angle.	✓	✓	✓
Mirror along Baseline - Mirror a series of points along a baseline as defined by two points.	✓	✓	✓
Shift / Average	Lt	Std	Pro
Shift by $\Delta X/\Delta Y/\Delta Z$ - Shift a series of points by entering northing/easting/elevation shift values.	✓	✓	✓
Shift by Distance and Direction - Shift a series of points by entering distance and direction shift values.	✓	✓	✓
Shift by From/To Points - Shift a series of points by entering two points to shift from/to.	✓	✓	✓
Average Points - Compute the average coordinate values of a series of points. The standard deviations of the averaged coordinates, and the coordinate ranges are calculated.	✓	✓	✓
Scale Points	Lt	Std	Pro
Scale from Base Point Scale a series of points from a base point by specified horizontal and vertical scale factors.	✓	✓	✓
Scale from Origin (0,0,0) Scale a series of points from 0,0,0 by specified horizontal and vertical scale factors.	✓	✓	✓
Transform Coordinates	Lt	Std	Pro
Helmert Transformation - Transform a series of points from one coordinate system to another by matching up control points in both systems. Points may be matched up 1D, 2D or 3D and the scale factor may be fixed at 1. The least squares solution computes the origin shift of the transformation, rotation and scale factor	—	✓	✓

Transform Coordinates	Lt	Std	Pro
-----------------------	----	-----	-----

parameters, the standard deviation in the northing/easting, the elevation shift and the residuals for each control pair.

3D to Plan Cross Section - Transform 3D point coordinates to 2D cross section points along a cut line as defined by two points.	-	✓	✓
--	---	---	---

Tools Menu



Triangle Solver	Lt	Std	Pro
-----------------	----	-----	-----

Plane Triangle Solver - Solve the remaining parts, area and perimeter of any plane triangle when providing 3 known parts.	✓	✓	✓
--	---	---	---

Horizontal Curves	Lt	Std	Pro
-------------------	----	-----	-----

Circular Curve Solver - The circular curve solver solves all the curve parameters when two parameters are provided, with one known parameter being either the radius or deflection angle, or provide the arc length and chord length to solve using Newton's method.	✓	✓	✓
---	---	---	---

Curve Through Fixed Point - Solves a curve that is required to fit fixed tangents and a fixed point on the curve.	✓	✓	✓
--	---	---	---

Spiral Curve Solver - The spiral curve solver solves all the parameters of a spiral-curve-spiral (equal spiral) transition curve when the spiral length, total SCS deflection angle and curve radius are provided.	-	✓	✓
---	---	---	---

Vertical Curves	Lt	Std	Pro
-----------------	----	-----	-----

Vertical Curve Solver - Solve a vertical curve by entering grades or elevations. Fixed point vertical curves and slope intersections are also included.	✓	✓	✓
--	---	---	---

Vertical Curves	Lt	Std	Pro
-----------------	----	-----	-----

1. Solve the elevation at any station on the vertical curve.
2. Solve the station(s) at a given elevation.
3. Solve the elevations for all stations at a given interval.

RPN Calculator	Lt	Std	Pro
----------------	----	-----	-----

RPN Calculator - RPN Calculator designed for survey calculations. Common distance/angle/area/volume unit support is included for direct calculations without the need to convert values prior to calculations.


✓ ✓ ✓

Configure Settings	Lt	Std	Pro
--------------------	----	-----	-----

User Settings - Angle and Distance Units, Coordinates, Stations and Grades formats, Input and Output Scale Factors, general Program options, and DXF export layer settings can be configured to the user's preference.

✓ ✓ ✓

Points Menu



Store and Edit Points	Lt	Std	Pro
-----------------------	----	-----	-----

Store and Edit Points - Store and edit point coordinates in the current project database.

✓ ✓ ✓


Delete Points	Lt	Std	Pro
---------------	----	-----	-----

Delete Points - Delete points from the current project database.

✓ ✓ ✓

Renumber Points	Lt	Std	Pro
By Starting Number - Enter a Start ID and a range of points to renumber.	✓	✓	✓
By Additive Number - Enter a additive number and a range of points to renumber.	✓	✓	✓
Plot Points	Lt	Std	Pro
Plot Points - Graphically display a range of points on the screen. Touch and keyboard navigation (pan/zoom) is possible.	✓	✓	✓
Import / Export	Lt	Std	Pro
Import ASCII Points - Import comma, space or tab delimited ASCII files.	—	✓	✓
Export ASCII Points - Export comma, space or tab delimited ASCII files, and choose the number of decimals.	—	✓	✓
Export DXF Points - Export DXF files of points in the project database to open directly in a CAD program.	—	✓	✓

Advanced Menu



Alignments	Lt	Std	Pro
Alignments - Create multiple complex 3D alignments with fully editable segments. The horizontal component of an alignment may include straight, curve, and spiral-curve-spiral segments. Vertical curves and straight grades can be used to define the vertical component, and cross section templates can be defined and assigned to portions of, or the whole alignment. Station equations are supported.	—	—	✓

Alignments	Lt	Std	Pro
------------	----	-----	-----

1. Solve the 3D coordinates for any station and offset along the alignment once defined.
2. Auto-store points at a specified station interval. Points are created at each cross section break when a template is assigned.
3. Export the alignment in **LandXML** format.

Leveling	Lt	Std	Pro
----------	----	-----	-----

Leveling - Create multiple Leveling projects with fully editable observation data.

1. Review/Export data in a field book style layout
2. Store calculated elevations to points in the current project database.
3. Calculate cuts/fills from any station in the Leveling project.
4. Export the Level network observations in **STAR*NET** input data format.

-	-	✓
---	---	---

Other Advanced Features	Lt	Std	Pro
-------------------------	----	-----	-----

The remaining features in the Advanced Menu are currently in the Planning Phase and will be available only for the **Professional** license level in the future.

-	-	✓
---	---	---